

PARTS LIST / LISTE DES PIECES

Y #	ITEM #	DESCRIPTION	DESCRIPTION	946-24	946-27	946-44	946-47	948-14B	948-17B	948-14S	948-17S
1	S11426	CASTING BOTTOM	FOND DU FOYER	1	1	1	1	1	1	1	1
2	S11250	CASTING TOP	COUVERCLE DU GRIL	1	1	1	1	1	1	1	1
3	10081-BK603	NAMEPLATE	PLAQUE D'IDENTIFICATION	1	1	1	1	1	1	1	1
3A	10081-BK601	NAMEPLATE	PLAQUE D'IDENTIFICATION	1	1	1	1	1	1	1	1
4	10958-K69	TOP CASTING INSERT	PANNEAU DE COUVERCLE	1	1	1	1	1	1	1	1
5	10571-6	HEAT INDICATOR	INDICATEUR DE CHALEUR	1	1	1	1	1	1	1	1
6	S21235	HINGE PIN	ATTACHE DE CHEVILLE	2	2	2	2	2	2	2	2
7	S21233	HITCH PIN/CLIP	ATTACHE DE CHEVILLE	6	6	6	6	6	6	6	6
9	10225-T407	GRID - PORCELAIN	GRILLE	2	2	2	2	2	2	2	2
10	10222-T425	FLAV-R-WAVE SS	FLAV-R-WAVE AI	1	1	1	1	1	1	1	1
11	S12206	GRID - WARMING RACK	GRILLE	*	*	*	*	1	1	1	1
	S12207	GRID - WARMING RACK	GRILLE	1	1	1	1	*	*	*	*
15	10390-T501	BURNER/VENTURI ASSY	ENSEMBLE DE BRULEUR	1	1	1	1	1	1	1	1
17	10342-244	ELECTRONIC IGNITOR	ALLUMEUR ÉLECTRONIQUE	1	1	*	*	1	1	1	1
	10342-245	ELECTRONIC IGNITOR	ALLUMEUR ÉLECTRONIQUE	*	*	1	1	*	*	*	*
18	10342-T301	ELECTRODE	ELECTRODE	1	1	1	1	1	1	1	1
21	10440-E70	CONTROL ASSY LP-2V	SOUPAPE, (GAZ PROPANE)	1	*	*	*	1	*	1	*
	10440-E71	CONTROL ASSY NG-2V	SOUPAPE, (GAZ NATUREL)	*	1	*	*	*	1	*	1
	10442-E72	CONTROL ASSY LP-3V	SOUPAPE, (GAZ PROPANE)	*	*	1	*	*	*	*	*
	10442-E73	CONTROL ASSY NG-3V	SOUPAPE, (GAZ NATUREL)	*	*	*	1	*	*	*	*
21A	S13467-091	HOSE-SIDE BURNER LP	TUYAU DU BRULEUR LATERAL PL	*	*	1	*	*	*	*	*
	S13467-132	HOSE-SIDE BURNER NG	TUYAU DU BRULEUR LATERAL GN	*	*	*	1	*	*	*	*
	Y-11230	COTTER PIN	ATTACHE DE CHEVILLE	*	*	1	1	*	*	*	*
22	10114-20	HOSE & REGULATOR LP - QCC1	TUYAU ET REGULATEUR PL - QCC1	1	*	1	*	1	*	1	*
	10111-K47	HOSE NATURAL GAS	TUYAU (GAZ NATUREL)	*	1	*	1	*	1	*	1
23	10472-K37	CONTROL KNOB	BOUTON DE CONTROLE	2	2	3	3	2	2	2	2
30	10086-E507	DECO PLATE - 2V	PLAQUE DECORATIVE - 2V	1	1	*	*	1	1	1	1
	10086-E517	DECO PLATE - 3V	PLAQUE DECORATIVE - 3V	*	*	1	1	*	*	*	*
31	10194-E501	CONTROL COVER	PANNEAU DE CONTROLE	1	1	1	1	1	1	1	1
33	10184-R80	RADIATION SHIELD	ÉCRAN DE CHALEUR	1	1	1	1	1	1	1	1
35	10184-E401	SUPPORT-CASTING-LEFT	SUPPORT GAUCHE DU FOYER	1	1	1	1	1	1	1	1
36	10184-E411	SUPPORT-CASTING-RIGHT	SUPPORT DROIT DU FOYER	1	1	1	1	1	1	1	1
37	10184-E461	SUPPORT-SIDE SHELF-LEFT	SUPPORT TABLETTE DE GAUCHE	2	2	2	2	2	2	2	2
37A	10184-E62	SUPPORT-SIDE SHELF-LEFT	SUPPORT TABLETTE DE GAUCHE	2	2	2	2	2	2	2	2
38	10184-E471	SUPPORT-SIDE SHELF-RIGHT	SUPPORT TABLETTE DE DROIT	2	2	2	2	2	2	2	2
38A	10184-E63	SUPPORT-SIDE SHELF-RIGHT	SUPPORT TABLETTE DE DROIT	2	2	2	2	2	2	2	2
39	10956-E561	BRACE-REAR	SUPPORT ARRIERE	1	1	1	1	1	1	1	1
40	10958-R81B	BASE	TABLETTE INFÉRIEURE	1	1	1	1	1	1	1	1
41	10956-E571	BRACE-FRONT	SUPPORT AVANT	1	1	1	1	1	1	1	1
42	10958-K881	FRONT PANEL BLACK	PANNEAU AVANT	1	1	1	1	1	1	1	1
43	10958-E661	SIDE PANEL BLACK	PANNEAU LATÉRALE	2	2	2	2	2	2	2	2
47	10184-R19	TANK RETAINER	SERVITEUR DU RESERVOIR	2	*	2	*	2	*	2	*
50	10711-E561	SHELF-SIDE-RIGHT	PLANCHETTE LATÉRALE - DROIT	1	1	1	1	1	1	1	1
51	10711-E562	SHELF-SIDE-LEFT	PLANCHETTE LATÉRALE - GAUCHE	1	1	*	*	1	1	1	1
	10711-E563	SHELF-SIDE-BURNER	PLANCHETTE - BRULEUR DE COTE	*	*	1	1	*	*	*	*
56	10892-7	WHEEL	ROUE	2	2	2	2	2	2	2	2
73	S21420	PUSH NUT	POUSSE ECROU	2	2	2	2	2	2	2	2
74	Y-6616	BOLT - 1/4-20 X 1 1/2	BOULON - 1/4-20 X 1 1/2	2	2	2	2	2	2	2	2
75	10338-145	HANDLE	POIGNEE	2	2	2	2	2	2	2	2
76	10239-6	WASHER-HANDLE	RONDELLE DE LA POIGNEE	2	2	2	2	2	2	2	2
78	10892-13	CASTOR	ROULETTES	2	2	2	2	2	2	2	2
79	Y-11561	BOLT - 1/4-20 X 1 3/4	BOULON - 1/4-20 X 1 3/4	8	8	8	8	8	8	8	8
80	Y-11546	SCREW - 1/4-20 X 5/8	VIS - 1/4-20 X 5/8	4	4	4	4	4	4	4	4
81	Y-11545	SCREW - 1/4-20 X 1 3/8	VIS - 1/4-20 X 1 3/8	4	4	4	4	4	4	4	4
82	Y-12673	SHELF - LOCK PIN	ÉTAGÈRE - GOUPILLE DE SERRURE	2	2	2	2	2	2	2	2
83	S21014	BOLT - 1/4-20 X 3/4	BOULON - 1/4-20 X 3/4	8	8	8	8	8	8	8	8
84	S15171	AXLE	ESSIEU	1	1	1	1	1	1	1	1
85	10240-15	HINGE PIN	ATTACHE DE CHEVILLE	4	4	4	4	4	4	4	4
87	Y-11793	NUT - 1/4-20	ECROU - 1/4-20	22	22	22	22	22	22	22	22
98	S21124	SCREW - 8 X 1/2	VIS - 8 X 1/2	20	20	20	20	20	20	20	20
99	Y-12646	SCREW - SHOULDER 8 X 1/2	VIS - 8 X 1/2	*	*	2	2	*	*	*	*
104	Y-12835	SCREW - 6-32 X 1/4	VIS - 6-32 X 1/4	*	*	2	2	*	*	*	*
105	Y-29307	NUT - 10-24	ECROU - 10-24	*	*	4	4	*	*	*	*
108	PB20-60	LID HANDLE	POIGNEE	*	*	1	1	*	*	*	*
109	S21136	SCREW - 8-32 X 3/8	VIS - 8-32 X 3/8	3	3	5	5	3	3	3	3
110	10225-T09	GRID	GRILLE	*	*	1	1	*	*	*	*
111	10390-E10	SIDE BURNER	BRULEUR DE COTE	*	*	1	1	*	*	*	*
113	10342-T14	ELECTRODE - SIDE BURNER	ELECTRODE - BRULEUR DE COTE	*	*	1	1	*	*	*	*
114	10393-E401	COVER-SIDE BURNER	COUVERCLE LATÉRAL	*	*	1	1	*	*	*	*
115	Y-29304	SCREW - 10-24 X 3/8	VIS - 10-24 X 3/8	2	2	8	8	2	2	2	2
117	10393-E62	SHELF-SIDE BURNER	SUPPORT DE BRULEUR DE COTE	*	*	1	1	*	*	*	*
123	S15115	GREASE PAN - DISPOSABLE	CUVETTE A GRAISSE	2	2	2	2	2	2	2	2