

PARTS LIST/LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	DESCRIPTION	956-24 956-27	956-44 956-47	956-74 956-77	956-94 956-97
73.	S21420	PUSH NUTS	POUSSE ECROU	2	2	2	2
74.	Y-6616	BOLT - 1/4:20 x 1 1/2	BOULON - 1/4:20 x 1 1/2	2	2	2	2
75.	10338-145	HANDLE	POIGNEE	2	2	2	2
76.	10239-6	WASHER - HANDLE	RONDELLE DE LA POIGNEE	2	2	2	2
78.	10892-14	CASTOR	ROULETTES	2	2	2	2
79.	S21017	BOLT - 1/4:20 x 1 3/4	BOULON - 1/4:20 X 1 3/4	2	2	2	2
80.	Y-11546	BOLT - 1/4:20 X 5/8	BOULON - 1/4:20 X 5/8	8	8	8	8
82.	Y-12860	SCREW - 1/4:20 X 1	VIS - 1/4:20 X 1	2	2	2	2
82A.	Y-12855	SCREW - 1/4:20 X 3/8	VIS - 1/4:20 X 3/8	16	16	16	16
83.	S21014	BOLT 1/4:20 X 3/4	BOULON 1/4:20 X 3/4	6	6	6	6
84.	S15178	AXLE	ESSIEU	1	1	1	1
87.	Y-11793	NUT - 1/4"	ECROU - 1/4"	22	22	22	22
88.	Y-11598	NUT WING - 1/4"	ECROU PAPILLON - 1/4"	2	2	2	2
98.	S21124	SCREW - 8 X 1/2"	VIS - 8 X 1/2"	28	28	28	28
99.	Y-12646	SCREW - SHOULDER	VIS	4	6	4	6
101.	Y-12853	WASHER - #8	RONDELLE - #8	4	4	4	4
104.	Y-12835	SCREW 6:32 X 1/4	VIS 6:32 X 1/4	*	2	*	2
105.	Y-29307	NUT - 10:24	ECROU - 10:24	*	4	*	4
108.	PB20-60	LID HANDLE	POIGNEE	*	1	*	1
109.	S21136	SCREW 8 - 32 X 3/8	VIS 8- 32 X 3/8	4	6	4	6
110.	10225-T10	GRID	GRILLE	*	1	*	1
111.	10390-E10	SIDE BURNER	BRULEUR DE COTE	*	1	*	1
113.	10342-T14	ELECTRODE & WIRE - SIDE BURNER	ELECTRODE & FER - BRULEUR DE COTE	*	1	*	1
114.	10393-K40	COVER - SIDE BURNER	COUVERCLE LATÉRAL	*	1	*	1
115.	Y-29305	SCREW 10:24 X 3/8	VIS 10:24 X 3/8	2	8	4	8
117.	10393-R50	SHELF - SIDE BURNER	SUPPORT DE BRULEUR DE COTE	*	1	*	1
120.	10184-K641	CASTOR SUPPORT	SUPPORT DE ROULETTE.	1	1	1	1
123.	S15115	GREASE PAN - DISPOSABLE	CUVETTE A GRAISSE	2	2	2	2