

ITEM #	PART ARTICLE #	DESCRIPTION	DESCRIPTION	BE50045-554	BE50045-557	BE50057-564	BE50057-567	BE50058-564	BE50058-567	BE50070-584	BE50070-587
1.01		COVER ASSY	COUVERCLE DU GRIL								
	SP45-1	BE500 COVER ASSY	COUVERCLE DU GRIL POUR BE500	1	1	1	1	1	1	1	1
1.02	SP384-9	500 COVER PANEL	PANNEAU DE CONTROLE	1	1	1	1	1	1	1	1
1.03	SP102-33	COVER CAST END CAP R.H.	CAPUCHON COTE DROITE DU COUVERCLE	1	1	1	1	1	1	1	1
1.04	SP103-33	COVER CAST END CAP L.H.	CAPUCHON COTE GAUCHE DU COUVERCLE	1	1	1	1	1	1	1	1
1.05	SP73A-19	500 COVER HANDLE	POIGNEE	1	1	1	1	1	1	1	1
1.06	SP74-19	HANDLE GRIP	POIGNEE DE POIGNEE	1	1	1	1	1	1	1	1
1.07 / 1.08	SP68-30	BLUE EMBER LOGO GAGE ASS+NUT	ENSEMBLE ET ECROU	1	1	1	1	1	1	1	1
1.09	SP112-18	SHOULDER BOLT	BOULON FORME L	2	2	2	2	2	2	2	2
2.01		FIRE BOX ASSY	FOND DU FOYER								
2.02		FIRE BOX BODY ASSY	FOND DU FOYER AU COMPLET								
2.03	SP20-38	LIGHT	LUMIERE	1	1	1	1	1	1	1	1
2.04	SP69-12	ROTIS INFARED BURNER	BRULEUR DE TOURNEBROCHE							1	1
2.05	SP95-6	LIGHT RAIN GUARD	CAPUCHON DE LUMIERE	1	1	1	1	1	1	1	1
2.06	SP55-20	ROTIS IGNITER PROBE ASSY	SONDE BE BOUGIE DE TOURNEBROCHE							1	1
2.07	SP51-6	VENTURI COVER	HOUSSE DE VENTURI							1	1
2.08	SP47-21	#8-32 X .375 PAN HEAD SCREW	VIS							8	8
2.09	SP44-16	#8-32 ACORN NUT	ECROU #8-32							8	8
2.10	SP11-25	STOP BUMPER	BUTOIR DE COUVERCLE	2	2	2	2	2	2	2	2
2.11	SP683-9	500 HEAT BAFFLE	ECRAN DE CHALEUR	1	1	1	1	1	1	1	1
2.12		CONSOLE ASSY	SOUPAPE								
2.13	SP391-9	CONSOLE TOP	DESSUS DE CONSOLE	1	1	1	1	1	1	1	1
2.14	SP900-41	CONSOLE BE500 3MB	PLAQUE DECORATIVE 3B	1	1						
	SP900-21	CONSOLE BE500 3MB+SB	PLAQUE DECORATIVE 3B+BRULEUR LATERALE			1	1				
	SP900-42	CONSOLE BE500 4MB+SB	PLAQUE DECORATIVE 4B+BRULEUR LATERALE					1	1		
	SP57-31	CONSOLE BE500 4MB+SB+RB	PLAQUE DECORATIVE 4B+BRULEUR LATERALE+BRULEUR DE TOURNEBROCHE							1	1
2.15	SP318-6	BEZEL-SIDE/ROTIS	MONTURE DE CONTROLE - BRULEUR LATERALE/TOURNEBROCHE			1	1	1	1	2	2
2.16	SP317-6	BEZEL-MAIN	MONTURE DE CONTROLE - PRINCIPALE	3	3	3	3	4	4	4	4
2.17	SP30-7	KNOB ASSY-SIDE-ROTIS	BOUTON DE CONTROLE-BRULEUR LATERALE/TOURNEBROCHE			1	1	1	1	2	2
2.18	SP29-7	KNOB ASSY-MAIN	BOUTON DE CONTROLE-PRINCIPALE	3	3	3	3	4	4	4	4
2.19	SP61-38	ROCKER SWITCH	INVERSEUR A RAPPEL	1	1	1	1	1	1	1	1
2.20	SP74-20	IGNITOR 3 POLE	ALLUMEUR A 3 TROUS	1	1						
	SP68-20	IGNITOR 4 POLE	ALLUMEUR A 4 TROUS			1	1				
	SP75-20	IGNITOR 5 POLE	ALLUMEUR A 5 TROUS					1	1		
	SP76-20	IGNITOR 6 POLE	ALLUMEUR A 6 TROUS							1	1
2.21		REGULATOR AND HOSE	TUYEAU ET REGULATEUR	1		1		1		1	
	SP18-11	NG 10" HOSE ASSY	TUYEAU DE GAZ NATURELLE		1		1		1		1
2.22	SP231A-4	BE500 3MB VALVE-LP ASSY	ENSEMBLE	1							
	SP248A-4	BE500 3MB VALVE-NG ASSY	ENSEMBLE		1						
	SP232B-4	BE500 3MB+SB VALVE-LP ASSY	ENSEMBLE			1					
	SP247B-4	BE500 3MB+SB VALVE-NG ASSY	ENSEMBLE				1				
	SP900-43	BE500 4MB+SB VALVE-LP ASSY	ENSEMBLE					1			
	SP921-4	BE500 4MB+SB VALVE-NG ASSY	ENSEMBLE						1		
	SP900-31	BE500 4MB+SB+RB VALVE-LP ASSY	ENSEMBLE							1	
	SP922-4	BE500 4MB+SB+RB VALVE-NG ASSY	ENSEMBLE								1
2.23	SP124-12	BE MAIN BURNER ASSY	ENSEMBLE DE BRULEUR	3	3	3	3	4	4	4	4
2.24	SP123-12	BE MAIN BURNER	ENSEMBLE DE BRULEUR PRINCIPALE BE	3	3	3	3	4	4	4	4
2.25	SP87-20	IGNITOR PIN	GOUPILLE D'ALLUMEUR	3	3	3	3	4	4	4	4
2.26	SP54-6	BASE SHELF BRACKET	SUPPORT-PLANCHETTE	4	4	4	4	4	4	4	4
2.27	SP56-21	1/4-B X 0.5 SS HEX HD FLANGED SCREW	VIS	8	8	8	8	8	8	8	8
2.28	SP53-16	1/4-20 FLANGE HEX NUT	ECROU - 1/4-20	14	14	14	14	14	14	14	14
2.29	SP85-18	SHOULDER BOLT	BOULON FORME L	8	8	8	8	8	8	8	8