

PARTS LIST / LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	DESCRIPTION	9867-74	9867-84	9869-84	9877-14	9877-34	9877-44	9877-84	9879-44
				9867-77	9867-87	9869-87	9877-17	9877-37	9877-47	9877-87	9879-47
1	10909-E400	CASTING BOTTOM	FOND DU FOYER	1	1	1	.	.	.	.	.
	10909-E450	CASTING BOTTOM	FOND DU FOYER	.	.	.	1	1	1	1	1
2	10473-E400	CASTING TOP	COUVERCLE DU GRIL	1	1	1	.	.	.	.	.
	10473-E450	CASTING TOP	COUVERCLE DU GRIL	.	.	.	1	1	1	1	1
3	10081-BK030	NAMEPLATE	PLAQUE D'IDENTIFICATION	1	1	1	1	1	1	1	1
4	10938-E400	TOP CASTING INSERT	PANNEAU DE COUVERCLE	1	1	1	.	.	.	.	.
	10938-E450	TOP CASTING INSERT	PANNEAU DE COUVERCLE	.	.	.	1	1	1	1	1
5	10571-6	HEAT INDICATOR	INDICATEUR DE CHALEUR	1	1	1	1	1	1	1	1
6	10240-15	HINGE PIN	GOUPILLE DE CHARNIERE	6	6	6	6	6	6	6	6
6A	S21237	HINGE SPACER	ENTRETOISE DE CHARNIERE	2	2	2	2	2	2	2	2
7	S21233	HITCH PIN CLIP	ATTACHE DE CHEVILLE	6	6	6	6	6	6	6	6
9	10225-T436	GRID - PORCELAIN	GRILLE	2	2	.	.	.	.	.	.
	10225-T536	GRID - PORCELAIN	GRILLE	.	.	.	3	.	.	2	.
	S12033S	GRID - S.S.	GRILLE - A.I.	.	.	.	.	3	3	.	3
	38170121	GRID - PORCELAIN	GRILLE	.	.	2	.	.	.	.	.
10	10222-E400	FLAV-R-WAVE	FLAV-R-WAVE	3	3	3	3	3	3	3	3
11	10225-E401	GRID - WARMING RACK	GRILLE	1	1	1	.	.	.	.	.
	10225-E451	GRID - WARMING RACK	GRILLE	.	.	.	1	1	1	1	1
12	10222-E401	DIVIDER	DIVISEUR	2	2	2	2	2	2	2	2
13	10184-R84	BOSS EXTENSION	CROCHET DE RALLONGEMENT	.	.	.	1	1	1	1	1
15	10390-E20	BURNER	BRÛLEUR	3	3	3	3	3	3	3	3
17	10342-245	ELECTRONIC IGNITOR	ALLUMEUR ELECTRONIQUE	1	.	.	.	1	.	.	.
	10342-246	ELECTRONIC IGNITOR	ALLUMEUR ELECTRONIQUE	.	1	1	.	.	1	1	1
18	10342-E12	ELECTRODE	ELECTRODE	2	2	2	2	2	2	2	2
19	10342-E400	COLLECTOR BOX	BOÎTE DE COLLECTEUR	1	1	1	1	1	1	1	1
19A	10342-E401	COLLECTOR BOX	BOÎTE DE COLLECTEUR	1	1	1	1	1	1	1	1
21	10444-E449	CONTROL ASSEMBLY - LP	ASSEMBLÉE DE CONTRÔLE	1/0	.	.	.	.	.	.	.
	10444-E459	CONTROL ASSEMBLY - NG	ASSEMBLÉE DE CONTRÔLE	0/1	.	.	.	.	.	.	.
	10444-E469	CONTROL ASSEMBLY - LP	ASSEMBLÉE DE CONTRÔLE	.	1/0	1/0	.	.	.	.	.
	10444-E479	CONTROL ASSEMBLY - NG	ASSEMBLÉE DE CONTRÔLE	.	0/1	0/1	.	.	.	.	.
	10444-E509	CONTROL ASSEMBLY - LP	ASSEMBLÉE DE CONTRÔLE	.	.	.	1/0	.	.	.	.
	10444-E519	CONTROL ASSEMBLY - NG	ASSEMBLÉE DE CONTRÔLE	.	.	.	0/1	.	.	.	.
	10444-E549	CONTROL ASSEMBLY - LP	ASSEMBLÉE DE CONTRÔLE	.	.	.	.	1/0	.	.	.
	10444-E559	CONTROL ASSEMBLY - NG	ASSEMBLÉE DE CONTRÔLE	.	.	.	.	0/1	.	.	.
	10444-E569	CONTROL ASSEMBLY - LP	ASSEMBLÉE DE CONTRÔLE	.	.	.	.	.	1/0	1/0	1/0
	10444-E579	CONTROL ASSEMBLY - NG	ASSEMBLÉE DE CONTRÔLE	.	.	.	.	.	0/1	0/1	0/1
21A.	S13470-091	HOSE-SIDE BURNER LP	TUYAU DU BRÛLEUR LATÉRAL PL	.	1/0	1/0	.	.	1/0	1/0	1/0
	S13470-132	HOSE-SIDE BURNER NG	TUYAU DU BRÛLEUR LATÉRAL GN	.	0/1	0/1	.	.	0/1	0/1	0/1
	Y-11230	COTTER PIN	ATTACHE DE CHEVILLE	.	1	1	.	.	1	1	1
21B.	10110-40	TUBE-REAR BURNER ASSY	TUBE DE BRÛLEUR ARRIÈRE	1	1	1	.	.	.	.	.
	10110-45	TUBE-REAR BURNER ASSY	TUBE DE BRÛLEUR ARRIÈRE	.	.	.	.	1	1	1	1
22	10114-20	HOSE & REGULATOR LP - QCC1	TUYAU ET RÉGULATEUR PL - QCC1	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0
	10111-K45	HOSE NATURAL GAS	TUYAU (GAZ NATUREL)	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
23	22001-768	CONTROL KNOB	BOUQUON DE CONTRÔLE	4	5	5	3	4	5	5	5
23A	10472-E38	CONTROL BEZEL	MONITURE DE CONTRÔLE	4	5	5	3	4	5	5	5
23B	Y-12674	CONTROL KNOB	BOUQUON DE CONTRÔLE	0/4	0/5	0/5	0/3	0/4	0/5	0/5	0/5
25	10222-E402	BAFFLE	PLAQUE-CHICANE	1	1	1	1	1	1	1	1
30	10194-E433	CONTROL COVER	PANNEAU DE CONTRÔLE	.	.	.	1	.	.	.	.
	10194-E477	CONTROL COVER	PANNEAU DE CONTRÔLE	1	.	.	.	1	.	.	.
	10194-E499	CONTROL COVER	PANNEAU DE CONTRÔLE	.	1	1	.	.	1	1	1
31	10711-E42	EDGE CAP - CONTROL COVER	PAC DE BORD	1	1	1	1	1	1	1	1
32	10711-E41	EDGE CAP - CONTROL COVER	PAC DE BORD	1	1	1	1	1	1	1	1
33	10184-E84	RADIATION SHIELD	ÉCRAN DE CHALEUR	1	1	1	1	1	1	1	1
35	10184-E901	SUPPORT-CASTING-LEFT	SUPPORT GAUCHE DU FOYER	1	1	1	1	1	1	1	1
36	10184-E511	SUPPORT-CASTING-RIGHT	SUPPORT DROIT DU FOYER	1	1	1	1	1	1	1	1
37	10184-E651	SUPPORT-SIDE SHELF-LEFT	SUPPORT TABLETTE DE GAUCHE	2	2	2	2	2	2	2	2
37A	10184-E63	SUPPORT-SIDE SHELF-LEFT	SUPPORT TABLETTE DE GAUCHE	2	2	2	2	2	2	2	2
38	10184-E641	SUPPORT-SIDE SHELF-RIGHT	SUPPORT TABLETTE DE DROIT	2	2	2	2	2	2	2	2
38A	10184-E62	SUPPORT-SIDE SHELF-RIGHT	SUPPORT TABLETTE DE DROIT	2	2	2	2	2	2	2	2
39	10936-E881	BRACE-REAR	SUPPORT ARRIÈRE	1	1	1	1	1	1	1	1
40	10938-E81	BASE	TABLETTE INFÉRIEURE	1	1	1	1	1	1	1	1
41	10936-E901	BRACE-FRONT	SUPPORT AVANT	1	1	1	1	1	1	1	1
42	10938-E79	DOOR	PORTE	2	2	2	2	2	2	2	2
42A	10938-E851	DOOR - INNER	PORTE INTÉRIEURE	2	2	2	2	2	2	2	2
43	10938-E77	SIDE PANEL S.S.	PANNEAU LATÉRAL A.I.	.	.	.	.	.	.	.	2
	10938-E761	SIDE PANEL BLK	PANNEAU LATÉRAL	2	2	2	2	2	2	2	.
44	10938-E901	PANEL - REAR	PANNEAU - ARRIÈRE	1	1	1	1	1	1	1	1
45	10184-E801	BRACKET - DOOR CATCH	CROCHET DE PORTE	1	1	1	1	1	1	1	1
47	10184-E691	SHELF BRACKET	SUPPORT POUR TABLETTE	2	2	2	2	2	2	2	2
48	10184-E681	BRACKET - SHELF	CROCHET - PLANCHETTE	2	2	2	2	2	2	2	2
49	10711-E61	CONDIMENT BIN	CASIER DE CONDIMENT	2	2	2	2	2	2	2	2
50	10711-E62	SHELF - SIDE - RIGHT	PLANCHETTE LATÉRALE - DROIT	2	1	1	2	2	1	1	1
51	10711-E63	SHELF-SIDE BURNER	PLANCHETTE - BRÛLEUR DE CÔTÉ	.	1	1	.	.	1	1	1