

PARTS LIST / LISTE DES PIECES

| KEY # | ITEM # | DESCRIPTION | DESCRIPTION | 958-74 | 958-94 | 969-24 | 969-44 | 969-74 | 969-94 | 5818-4 | 5848-4 | |
|-----------|-------------|----------------------|---------------------------------|-------------------------------|--------|--------|--------|--------|--------|--------|--------|---|
| | | | | 958-77 | 958-97 | 969-27 | 969-47 | 969-77 | 969-97 | 5818-7 | 5848-7 | |
| 1 | 10909-T45 | CASTING BOTTOM | FOND DU FOYER | 1 | 1 | - | - | - | - | - | - | |
| | 10909-T50 | CASTING BOTTOM | FOND DU FOYER | - | - | - | - | - | - | 1 | 1 | |
| | 10909-T60 | CASTING BOTTOM | FOND DU FOYER | - | - | 1 | 1 | 1 | 1 | - | - | |
| 2 | 10473-T45 | CASTING TOP | COUVERCLE DU GRIL | 1 | 1 | - | - | - | - | - | - | |
| | 10473-T50 | CASTING TOP | COUVERCLE DU GRIL | - | - | - | - | - | - | 1 | 1 | |
| | 10473-T60 | CASTING TOP | COUVERCLE DU GRIL | - | - | 1 | 1 | 1 | 1 | - | - | |
| 3 | 10081-BK603 | NAMEPLATE | PLAQUE D'IDENTIFICATION | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| 3A. | 10081-BK601 | NAMEPLATE | PLAQUE D'IDENTIFICATION | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| 4 | 10958-K70 | TOP CASTING INSERT | PANNEAU DE COUVERCLE | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| 5 | 10571-6 | HEAT INDICATOR | INDICATEUR DE CHALEUR | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| 6 | 10240-15 | HINGE PIN | ATTACHE DE CHEVILLE | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | |
| 6A. | S21237 | HINGE PIN SPACER | ESPACEUR DE CHEVILLE CHARNIERES | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | |
| 7 | S21233 | HITCH PIN CLIP | ATTACHE DE CHEVILLE | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | |
| 9 | 10225-T429 | GRID - PORCELAIN | GRILLE | 2 | 2 | - | - | - | - | - | - | |
| | 10225-T536 | GRID - PORCELAIN | GRILLE | - | - | - | - | - | - | 3 | 3 | |
| | 10225-T626 | GRID - PORCELAIN | GRILLE | - | - | 3 | 3 | 3 | 3 | - | - | |
| 10 | 10222-T425 | FLAV-R-WAVE SS | FLAV-R-WAVE SS | 1 | 1 | - | - | - | - | 1 | 1 | |
| | 10222-T626 | FLAV-R-CAST | FLAV-R-CAST | - | - | 2 | 2 | 2 | 2 | - | - | |
| 11 | 10225-T451 | GRID - WARMING RACK | GRILLE | 1 | 1 | - | - | - | - | - | - | |
| | 10225-T528 | GRID - WARMING RACK | GRILLE | - | - | - | - | - | - | 1 | 1 | |
| | 10225-T628 | GRID - WARMING RACK | GRILLE | - | - | 1 | 1 | 1 | 1 | - | - | |
| 12 | 10225-T627 | SWING BASKET | PANIER À BALANCOIR | - | - | 1 | 1 | 1 | 1 | 1 | 1 | |
| 13 | Y-11797 | BOLT SWING BASKET | BOULON POUR PANIER A BALANCOIR | - | - | 2 | 2 | 2 | 2 | 2 | 2 | |
| 15 | 10390-T501 | BURNER/VENTURI ASSY | ENSEMBLE DE BRULEUR | 1 | 1 | 1 | 1 | 1 | 1 | - | - | |
| | S10017 | BURNER/VENTURI ASSY | ENSEMBLE DE BRULEUR | - | - | - | - | - | - | 1 | 1 | |
| 17 | 10342-242 | ROTARY IGNITOR | ALLUMEUR ROTATIF | 1 | - | 1 | - | 1 | - | 1 | - | |
| | 10342-243 | ROTARY IGNITOR | ALLUMEUR ROTATIF | - | 1 | - | 1 | - | 1 | - | 1 | |
| | 10472-K40 | ROTARY IGNITOR KNOB | BOUTON ROTATOIRE D'IGNITOR | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| 18 | S21124S | SCREW - 8 x 1/2 S.S. | VIS - 8 X 1/2 S.S. | 2 | 2 | 2 | 2 | 2 | 2 | - | - | |
| | 10342-T301 | ELECTRODE | ELECTRODE | 2 | 2 | 2 | 2 | 2 | 2 | - | - | |
| 21 | S15500 | ELECTRODE | ELECTRODE | - | - | - | - | - | - | 2 | 2 | |
| | 10440-R70 | CONTROL ASSY LP-3V | SOUPAPE, (GAZ PROPANE) | 1 | - | - | - | - | - | - | - | |
| | 10440-R71 | CONTROL ASSY NG-3V | SOUPAPE, (GAZ NATUREL) | 1 | - | - | - | - | - | - | - | |
| | 10442-R58 | CONTROL ASSY LP-4V | SOUPAPE, (GAZ PROPANE) | - | 1 | - | - | - | - | - | - | |
| | 10442-R59 | CONTROL ASSY NG-4V | SOUPAPE, (GAZ NATUREL) | - | 1 | - | - | - | - | - | - | |
| | 10440-D60 | CONTROL ASSY LP-2V | SOUPAPE, (GAZ PROPANE) | - | - | 1 | - | - | - | - | - | |
| | 10440-D61 | CONTROL ASSY NG-2V | SOUPAPE, (GAZ NATUREL) | - | - | 1 | - | - | - | - | - | |
| | 10442-D62 | CONTROL ASSY LP-3V | SOUPAPE, (GAZ PROPANE) | - | - | - | 1 | - | - | - | - | |
| | 10442-D63 | CONTROL ASSY NG-3V | SOUPAPE, (GAZ NATUREL) | - | - | - | 1 | - | - | - | - | |
| | 10440-R64 | CONTROL ASSY LP-3V | SOUPAPE, (GAZ PROPANE) | - | - | - | - | 1 | - | - | - | |
| | 10440-R65 | CONTROL ASSY NG-3V | SOUPAPE, (GAZ NATUREL) | - | - | - | - | 1 | - | - | - | |
| | 10442-R66 | CONTROL ASSY LP-4V | SOUPAPE, (GAZ PROPANE) | - | - | - | - | - | 1 | - | - | |
| | 10442-R67 | CONTROL ASSY NG-4V | SOUPAPE, (GAZ NATUREL) | - | - | - | - | - | 1 | - | - | |
| | 10440-D80 | CONTROL ASSY LP-2V | SOUPAPE, (GAZ PROPANE) | - | - | - | - | - | - | 1 | - | |
| | 10440-D81 | CONTROL ASSY NG-2V | SOUPAPE, (GAZ NATUREL) | - | - | - | - | - | - | 1 | - | |
| | 10442-R86 | CONTROL ASSY LP-4V | SOUPAPE, (GAZ PROPANE) | - | - | - | - | - | - | - | 1 | |
| | 10442-R87 | CONTROL ASSY NG-4V | SOUPAPE, (GAZ NATUREL) | - | - | - | - | - | - | - | 1 | |
| | 21A. | S13467-091 | HOSE-SIDE BURNER LP | TUYAU DU BRULEUR LATERAL PL | - | 1 | - | 1 | - | 1 | - | 1 |
| | | S13467-132 | HOSE-SIDE BURNER NG | TUYAU DU BRULEUR LATERAL GN | - | 1 | - | 1 | - | 1 | - | 1 |
| | 21B. | Y-11230 | COTTER PIN | ATTACHE DE CHEVILLE | - | 1 | - | 1 | - | 1 | - | 1 |
| | | 10110-91 | TUBE-REAR BURNER ASSY | TUBE DE BRULEUR ARRIERE | 1 | 1 | - | - | 1 | 1 | - | 1 |
| | 22 | 10114-20 | HOSE & REGULATOR LP - QCC1 | TUYAU ET REGULATEUR PL - QCC1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 10111-K47 | | HOSE NATURAL GAS | TUYAU (GAZ NATUREL) | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| 23 | 10472-K37 | CONTROL KNOB | BOUTON DE CONTROLE | 3 | 4 | 2 | 3 | 3 | 4 | 2 | 4 | |
| 30 | 10086-D561 | DECO PLATE-3V | PLAQUE DECORATIVE | 1 | - | - | - | - | - | - | - | |
| | 10086-D571 | DECO PLATE-4V | PLAQUE DECORATIVE | - | - | 1 | - | - | - | - | - | |
| | 10086-R541 | DECO PLATE-2V | PLAQUE DECORATIVE | - | - | - | - | - | - | 1 | - | |
| | 10086-R571 | DECO PLATE-4V | PLAQUE DECORATIVE | - | - | - | - | - | - | - | 1 | |
| 30A. | 10086-D54 | DECO PLATE-REGAL | PLAQUE DECORATIVE | 1 | 1 | - | - | - | - | - | - | |
| | 10086-R63 | DECO PLATE -SIGNET | PLAQUE DECORATIVE | - | - | - | - | - | - | 1 | 1 | |
| | 10081-BK613 | NAMEPLATE | PLAQUE D'IDENTIFICATION | - | - | 1 | 1 | 1 | 1 | - | - | |