

PARTS LIST/LISTE DES PIECES

#	#	DESCRIPTION	DESCRIPTION	551-24	551-27	553-24	553-27	554-24	554-2
87A.	Y-11795	LOCK NUT - 1/4	ECROU DE SERRURE	4	4	4	4	4	4
89.	Y-11212	TINNERMAN NUT	ECROU TINNERMAN	4	4	4	4	4	4
90.	Y-11560	BOLT - 1/4:20 x 1-1/2	BOULON - 1/4:20 x 1-1/2	8	8	8	8	8	8
91.	Y-11968	PAN HEAD BOLT 3/8 : 18 x 1 3/4	BOULON	4	4	4	4	4	4
92.	Y-11211	LOCK WASHER - 1/4	RONDELLE / DE BLOCAGE - 3/8	2	2	2	2	2	2
93.	Y-12852	LOCK WASHER - 3/8	RONDELLE / DE BLOCAGE - 1/4	2	2	2	2	2	2
94.	Y-12285	NUT - 3/8	ECROU - 3/8	4	4	4	4	4	4
96.	Y-29305	BOLT - 10:24 X 3/8	BOULON - 10:24 X 3/8	*	*	*	*	4	4
96A.	Y-29305S	BOLT - 10:24 X 3/8	BOULON - 10:24 X 3/8	2	2	4	4	4	4
97.	10240-13	WHEEL BOLT	ROUE BOULON	2	2	2	2	2	2
98.	S21124	SCREW - 8 X 1/2	VIS - 8 X 1/2	12	12	12	12	12	12
98A.	S21124S	SCREW - 8 X 1/2	VIS - 8 X 1/2	10	10	10	10	10	10
99.	Y12648	SCREW SHOULDER - 8 x 1/2	Vis - 8 x 1/2	*	*	*	*	2	2
105.	Y-29307	NUT - 10:24	ECROU - 10:24	*	*	*	*	4	4
106.	Y-12835	SCREW - 6-32 x 1/4	VIS - 6-32 x 1/4	*	*	*	*	2	2
107.	S21136	SCREW - 8-32 x 3/8	VIS - 8-32 x 3/8	1	1	1	1	3	3
108.	PB20-60	LID HANDLE	POIGNEE	*	*	*	*	1	1
109.	S21562	PUSHMOUNT CABLE	RUBAN D'ACIER	*	*	*	*	1	1
110.	10225-T09	GRID	GRILLE	*	*	*	*	1	1
111.	10390-E10	SIDE BURNER	BRULEUR DE COTE	*	*	*	*	1	1
113	10342-T14	ELECTRODE - SIDE BURNER	ELECTRODE - BRULEUR DE COTE	*	*	*	*	1	1
114.	10393-E401	COVER - SIDE BURNER	COUVERCLE LATERAL	*	*	*	*	1	1
117.	10393-E60	SHELF-SIDE BURNER	SUPPORT DE BRULEUR DE COTE	*	*	*	*	1	1
123.	10184-E60	CASTER INSERT	EMBOUT POUR ROULETTE	2	2	2	2	2	2
124.	Y-12083	LOCK NUT - 10:24	ECROU DE SERRURE	4	4	4	4	4	4
125.	Y-12848	BOLT - 10:24 X 3/8	BOULON - 10:24 x 3/8	4	4	4	4	4	4
126.	Y-12642	SCREW - 8 X 1/2	VIS - 8 X 1/2	4	4	4	4	4	4