

PARTS LIST/LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	DESCRIPTION	942-24	942-44
				942-27	942-47
101	Y-12853	WASHER - #8	RONDELLE - #8	4	8
104	Y-12835	SCREW 6-32 X 1/4	VIS 6-32 X 1/4	8	9
105	Y-29307	NUT - 10-24	ECROU - 10-24	•	13
108	PB20-60	LID HANDLE	POIGNEE	•	1
109	S21136	SCREW 8-32 X 3/8	VIS 8-32 X 3/8	•	2
110	10225-T10	GRID	GRILLE	•	1
111	10390-T10	SIDE BURNER	BRULEUR DE COTE	•	1
113	10342-T08	ELECTRODE - SIDE BURNER	ELECTRODE - BRULEUR DE COTE	•	1
114	10393-K40	COVER - SIDE BURNER	COUVERCLE LATÉRAL	•	1
115	Y-29305	SCREW 10-24 X 3/8	VIS 10-24 X 3/8	4	8
117	10393-K50	SHELF - SIDE BURNER	SUPPORT DE BRULEUR DE COTE	•	1
118	10393-T221	SHIELD - SIDE BURNER	ECRAN DE CUVETTE LATÉRAL	•	1