

PARTS LIST/LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	DESCRIPTION	942-24	942-44	952-24	953-24	952-44	952-74	952-94	953-94
				942-27	942-47	952-27	953-27	952-47	952-77	952-97	953-97
50.	10711-K551	SHELF - SIDE	PLANCHETTE LATÉRALE	2	1	2	•	1	2	1	•
51.	10711-K60	SHELF - SIDE SS	PLANCHETTE LATÉRALE AI	•	•	•	2	•	•	•	1
53.	S16142-2	SHELF BOARD - FRONT	PLANCHETTE AVANT	1	1	•	•	•	•	•	•
	S16144-2	SHELF BOARD - FRONT	PLANCHETTE AVANT	•	•	1	•	1	1	1	•
54.	10088-14	FRONT PANEL	PANNEAU AVANT	1	1	•	•	•	•	•	•
	10088-15	FRONT PANEL	PANNEAU AVANT	•	•	1	1	1	1	1	1
55.	10184-K631	FRONT PANEL BRACKET	SUPPORT POUR PANNEAU AVANT	2	2	2	2	2	2	2	2
56.	10892-8	WHEEL	ROUE	2	2	2	2	2	2	2	2
57.	10156-K40	SHIELD	ECRAN	1	1	•	•	•	•	•	•
	10156-K55	SHIELD	ECRAN	•	•	1	1	1	1	1	1
65.	S13003	BURNER ROTISSERIE	BRULEUR A ROTISS	•	•	•	•	•	1	1	1
66.	10339-K901	BRACKET ORIFICE	SUPPORT D'ORIFICE	•	•	•	•	•	1	1	1
68.	S21361	SPRING	RESSORT	•	•	•	•	•	1	1	1
69.	S21381	SCREW - 12 X 1/2	VIS - 12 X 1/2	•	•	•	•	•	2	2	2
74.	Y-6616	BOLT	BOULON	2	2	2	2	2	2	2	2
75.	10338-145	HANDLE	POIGNEE	2	2	2	2	2	2	2	2
76.	10239-6	WASHER - HANDLE	RONDELLE DE LA POIGNEE	2	2	2	2	2	2	2	2
77.	S15111	GREASE CUP HOLDER	PORTE CONTENANT A GRAISSE	1	1	1	1	1	1	1	1
78.	10892-12	CASTOR	ROULETTES	2	2	2	2	2	2	2	2
79.	10228	TOOLS HOOKS	CROCHETS A OUTILS	•	•	•	8	•	•	•	4
80.	Y-11549	BOLT - 1/4:20 X 1-7/8	BOULON - 1/4:20 X 1-7/8	20	20	20	20	20	20	20	20
82.	Y12860	SCREW -1/4:20 X 1"	VIS -1/4:20 X 1"	4	4	4	4	4	4	4	4
83.	S21141	BOLT - 1/4:20 X 5/8	BOULON - 1/4:20 X 5/8	1	1	1	1	1	1	1	1
85.	S21255	WASHER	RONDELLE	1	1	1	1	1	1	1	1
86.	Y-12656	PLUG - BUTTON	BOUCHON	2	2	2	2	2	2	2	2
87.	Y-11793	NUT - 1/4	ECROU - 1/4	10	10	10	10	10	10	10	10
88.	Y-11598	NUT WING - 1/4	ECROU PAPILLON - 1/4	19	19	19	19	19	19	19	19
89.	Y-11212	NUT TINNEMAN - 1/4	ECROU TINNEMAN - 1/4	6	6	6	6	6	6	6	6
91.	Y-11967	BOLT - 3/8:16 X 1-3/4	BOULON - 3/8:16 X 1-3/4	2	2	2	2	2	2	2	2
94.	Y-12287	NUT - 3/8	ECROU - 3/8	2	2	2	2	2	2	2	2
96.	Y-29305	BOLT 10:24 X 3/8	BOULON 10:24 X 3/8	4	8	4	4	8	6	8	8
97.	10240-13	WHEEL BOLT	ROUE BOULON	2	2	2	2	2	•	•	•
98.	S21123	SCREW - 8 X 1/2	VIS - 8 X 1/2	20	17	20	20	17	20	17	17
99.	Y-12646	SCREW - SHOULDER	VIS	4	4	4	4	4	4	4	4
101.	Y-12853	WASHER - #8	RONDELLE - #8	4	8	4	4	8	4	8	8
104.	Y- 12835	SCREW 6-32 X 1/4	VIS 6-32 X 1/4	8	9	8	8	9	8	9	9
105.	Y-29307	NUT - 10:24	ECROU - 10:24	•	13	•	•	13	•	13	13
108.	PB20-60	LID HANDLE	POIGNEE	•	1	•	•	1	•	1	1
110.	10225-T10	GRID	GRILLE	•	1	•	•	1	•	1	1
111.	10390-T10	SIDE BURNER	BRULEUR DE COTE	•	1	•	•	1	•	1	1
113.	10342-T08	ELECTRODE - SIDE BURNER	ELECTRODE - BRULEUR DE COTE	•	1	•	•	1	•	1	1
114.	10393-K40	COVER - SIDE BURNER	COUVERCLE LATÉRAL	•	1	•	•	1	•	1	1
115.	Y-29305	SCREW 10:24 X 3/8	VIS 10:24 X 3/8	•	4	•	•	4	•	4	4
117.	10393-K50	SHELF - SIDE BURNER	SUPPORT DE BRULEUR DE COTE	•	1	•	•	1	•	1	1
118.	10393-T221	SHIELD - SIDE BURNER	ECRAN DE CUVETTE LATÉRAL	•	1	•	•	1	•	1	1