

PARTS LIST/LISTE DES PIECES

ΔEY #	ITEM #	DESCRIPTION	DESCRIPTION	531-04	542-14	542-17	542-34	553-14	553-17	553-34
1.	10909-T24	CASTING BOTTOM	FOND DU FOYER	1	•	•	•	•	•	•
	10909-T32	CASTING BOTTOM	FOND DU FOYER	•	1	1	1	•	•	•
	10909-T45	CASTING BOTTOM	FOND DU FOYER	•	•	•	•	1	1	1
2.	10473-T24	CASTING TOP	COUVERCLE DU GRIL	1	•	•	•	•	•	•
	10473-T32	CASTING TOP	COUVERCLE DU GRIL	•	1	1	1	•	•	•
	10473-T42	CASTING TOP	COUVERCLE DU GRIL	•	•	•	•	1	1	1
3.	10081-BK24	NAMEPLATE	PLAQUE D'IDENTIFICATION	1	•	•	•	•	•	•
	10081-BK321	NAMEPLATE	PLAQUE D'IDENTIFICATION	•	1	1	1	•	•	•
	10081-BK427	NAMEPLATE	PLAQUE D'IDENTIFICATION	•	•	•	•	1	1	1
5.	10571-5	HEAT INDICATOR	INDICATEUR DE CHALEUR	•	1	1	1	1	1	1
7.	S21233	HINGE CLIP	ATTACHE DE CHEVILLE	2	2	2	2	2	2	2
8.	10222-T24	GRATE	GRILL POUR BRIQUETTES	1	•	•	•	•	•	•
	10222-T32	GRATE	GRILL POUR BRIQUETTES	•	1	1	1	•	•	•
	10222-T424	FLAV-R-WAVE	FLAV-R-WAVE	•	•	•	•	1	1	1
9.	10225-T242	GRID - PORCELAIN	GRILLE	1	•	•	•	•	•	•
	10225-T322	GRID - PORCELAIN	GRILLE	•	2	2	2	•	•	•
	10225-T422	GRID - PORCELAIN	GRILLE	•	•	•	•	1	1	1
	10225-T423	GRID - PORCELAIN	GRILLE	•	•	•	•	1	1	1
	10225-T429	GRID - CAST IRON	GRILLE	•	•	•	•	•	•	•
11.	10225-T247	GRID RETRACTABLE	GRILLE RETRACTABLE	1	•	•	•	•	•	•
	10225-T327	GRID RETRACTABLE	GRILLE RETRACTABLE	•	1	1	1	•	•	•
	10225-T427	GRID RETRACTABLE	GRILLE RETRACTABLE	•	•	•	•	1	1	1
14.	10010-33	BRIQUETS - CERAMIC	BRIQUETTES - CERAMIQUE	1	•	•	•	•	•	•
	10010-45	BRIQUETS - CERAMIC	BRIQUETTES - CERAMIQUE	•	1	1	1	•	•	•
15.	10390-T301	BURNER ASSY	ENSEMBLE DE BRULEUR	1	•	•	•	•	•	•
	10390-T401	BURNER ASSY	ENSEMBLE DE BRULEUR	•	1	1	1	•	•	•
	10390-T501	BURNER ASSY	ENSEMBLE DE BRULEUR	•	•	•	•	1	1	1
17.	10342-21	IGNITOR	ALLUMEUR	1	1	1	•	1	1	•
	10342-22	IGNITOR	ALLUMEUR	•	•	•	1	•	•	1
18.	10342-T301	ELECTRODE	ELECTRODE	1	1	1	1	1	1	1
21.	10440-T31	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	1	•	•	•	•	•	•
	10440-T40	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	1	•	•	•	•	•
	10440-T41	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	•	1	•	•	•	•
	10442-T42	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	•	•	1	•	•	•
	10440-T50	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	•	•	•	1	•	•
	10440-T51	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	•	•	•	•	1	•
	10442-T52	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	•	•	•	•	•	1
21A.	S13467-091	HOSE - SIDE BURNER LP	TUYAU DU BRULEUR LATERAL PL	•	•	•	1	•	•	1
	S13467-132	HOSE - SIDE BURNER NG	TUYAU DU BRULEUR LATERAL GN	•	•	•	•	•	•	•
	Y-11230	COTTER PIN	ATTACHE DE CHEVILLE	•	•	•	1	•	•	1
22.	10114-17	HOSE & REGULATOR LP - QCC1	TUYAU ET REGULATEUR PL - QCC1	1	1	•	1	1	•	1
	10111-K47	HOSE & REGULATOR NG	TUYAU ET REGULATEUR NG	•	•	1	•	•	1	•
23.	10472-K36	CONTROL KNOB	BOUTON DE CONTROLE	2	2	2	3	2	2	3
30.	10086-T401	DECO PLATE	PLAQUE DECORATIVE	1	1	1	•	•	•	•
	10086-T411	DECO PLATE	PLAQUE DECORATIVE	•	•	•	1	•	•	•
	10086-T501	DECO PLATE	PLAQUE DECORATIVE	•	•	•	•	1	1	•
	10086-T511	DECO PLATE	PLAQUE DECORATIVE	•	•	•	•	•	•	1
31.	10194-T401	CONTROL COVER	PANNEAU DE CONTROLE	1	1	1	1	•	•	•
	10194-T501	CONTROL COVER	PANNEAU DE CONTROLE	•	•	•	•	1	1	1
32.	10338-T311	POST LEG	PIEDS	4	4	4	4	•	•	•
	S17317	POST LEG	PIEDS	•	•	•	•	4	4	4
35.	10184-T401	SUPPORT - CASTING - LEFT	SUPPORT GAUCHE DU FOYER	1	1	1	1	1	1	1
36.	10184-T411	SUPPORT - CASTING - RIGHT	SUPPORT DROIT DU FOYER	1	1	1	1	1	1	1
37.	S21345	PLUG - 1/2	EMBOUT DE JAMBE - 1/2	•	•	•	2	•	•	2
39.	10956-T401	BRACE - UPPER REAR	SUPPORT ARRIERE	1	1	1	1	•	•	•
	10956-T501	BRACE - UPPER REAR	SUPPORT ARRIERE	•	•	•	•	1	1	1
40.	S17346	SHELF - LOWER	TABLETTE INFERIEURE	1	1	1	1	•	•	•
	S17347	SHELF - LOWER	TABLETTE INFERIEURE	•	•	•	•	1	1	1
46.	S17106	BRACKET - CYLINDER LP	SUPPORT DU RESERVOIR PL	1	1	•	1	1	•	1
49.	10711-T461	CONDI-BIN	CONDI-BIN	•	1	1	1	•	•	•
	10711-T561	CONDI-BIN	CONDI-BIN	•	•	•	•	1	1	1
50.	10711-T451	SHELF - SIDE	PLANCHETTE LATERALE	2	2	2	•	•	•	•
	10711-K551	SHELF - SIDE	PLANCHETTE LATERALE	•	•	•	1	2	2	1