

PARTS LIST/LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	DESCRIPTION	531-04	542-14	542-17	542-34	552-04	552-07	552-14	552-17	552-34
1.	10909-T24	CASTING BOTTOM	FOND DU FOYER	1	.	.	.	.	.	.	.	.
	10909-T32	CASTING BOTTOM	FOND DU FOYER	.	1	1	1	.	.	.	.	.
	10909-T42	CASTING BOTTOM	FOND DU FOYER	.	.	.	.	1	1	1	1	1
2.	10473-T24	CASTING TOP	COUVERCLE DU GRIL	1	.	.	.	.	.	.	.	.
	10473-T32	CASTING TOP	COUVERCLE DU GRIL	.	1	1	1	.	.	.	.	.
	10473-T42	CASTING TOP	COUVERCLE DU GRIL	.	.	.	.	1	1	1	1	1
3.	10081-BK24	NAMEPLATE	PLAQUE D'IDENTIFICATION	1	.	.	.	.	.	.	.	.
	10081-BK321	NAMEPLATE	PLAQUE D'IDENTIFICATION	.	1	1	1	.	.	.	.	.
	10081-BK427	NAMEPLATE	PLAQUE D'IDENTIFICATION	.	.	.	.	1	1	1	1	1
5.	10571-5	HEAT INDICATOR	INDICATEUR DE CHALEUR	.	1	1	1	1	1	1	1	1
7.	S21233	HINGE CLIP	ATTACHE DE CHEVILLE	2	2	2	2	2	2	2	2	2
8.	10222-T24	GRATE	GRILL POUR BRIQUETTES	1	.	.	.	.	.	.	.	.
	10222-T32	GRATE	GRILL POUR BRIQUETTES	.	1	1	1	.	.	.	.	.
	10222-T42	GRATE	GRILL POUR BRIQUETTES	.	.	.	.	1	1	1	1	1
9.	10225-T241	GRID - NICKEL	GRILLE	.	.	.	.	.	.	.	.	.
	10225-T242	GRID - PORCELAIN	GRILLE	1	.	.	.	.	.	.	.	.
	10225-T322	GRID - PORCELAIN	GRILLE	.	2	2	2	.	.	.	.	.
	10225-T422	GRID - PORCELAIN	GRILLE	.	.	.	.	1	1	1	1	1
	10225-T423	GRID - PORCELAIN	GRILLE	.	.	.	.	1	1	1	1	1
11.	10225-T247	GRID RETRACTABLE	GRILLE RETRACTABLE	1	.	.	.	.	.	.	.	.
	10225-T327	GRID RETRACTABLE	GRILLE RETRACTABLE	.	1	1	1	.	.	.	.	.
	10225-T428	GRID RETRACTABLE	GRILLE RETRACTABLE	.	.	.	.	1	1	1	1	1
14.	10010-33	BRIQUETS - CERAMIC	BRIQUETTES - CERAMIQUE	1	.	.	.	.	.	.	.	.
	10010-45	BRIQUETS - CERAMIC	BRIQUETTES - CERAMIQUE	.	1	1	1	.	.	.	.	.
	10010-55	BRIQUETS - CERAMIC	BRIQUETTES - CERAMIQUE	.	.	.	.	1	1	1	1	1
15.	10390-T301	BURNER ASSY	ENSEMBLE DE BRULEUR	1	.	.	.	.	.	.	.	.
	10390-T401	BURNER ASSY	ENSEMBLE DE BRULEUR	.	1	1	1	.	.	.	.	.
	10390-T501	BURNER ASSY	ENSEMBLE DE BRULEUR	.	.	.	.	1	1	1	1	1
17.	10342-21	IGNITOR	ALLUMEUR	1	1	1	1	1	1	1	1	1
	10342-22	IGNITOR	ALLUMEUR	.	.	.	1	.	.	.	.	.
18.	10342-T301	ELECTRODE	ELECTRODE	1	1	1	1	1	1	1	1	1
21.	10440-T31	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	1	.	.	.	.	.	.	.	.
	10440-T40	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	.	1	.	.	.	.	.	.	.
	10440-T41	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	.	.	1	.	.	.	.	.	.
	10440-T42	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	.	.	.	1	.	.	.	.	.
	10440-T50	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	.	.	.	.	1	.	1	.	.
	10440-T51	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	.	.	.	.	.	1	.	1	.
	10440-T52	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	.	.	.	.	.	.	.	.	1
21A.	S10125	HOSE - SIDE BURNER LP	TUYAU DU BRULEUR LATERAL PL	.	.	.	1	.	.	.	.	1
22.	10114-20	HOSE & REGULATOR LP - QCC1	TUYAU ET REGULATEUR PL - QCC1	1	1	.	1	1	.	1	.	1
	10111-K47	HOSE & REGULATOR NG	TUYAU ET REGULATEUR NG	.	.	1	.	.	1	.	1	.
23.	10472-K36	CONTROL KNOB	BOUTON DE CONTROLE	2	2	2	3	2	2	2	2	3
30.	10086-T401	DECO PLATE	PLAQUE DECORATIVE	1	1	1	.	.	.	.	.	.
	10086-T411	DECO PLATE	PLAQUE DECORATIVE	.	.	.	1	.	.	.	.	.
	10086-T501	DECO PLATE	PLAQUE DECORATIVE	.	.	.	.	1	1	1	1	.
	10086-T511	DECO PLATE	PLAQUE DECORATIVE	.	.	.	.	.	.	.	.	1
31.	10194-T401	CONTROL COVER	PANNEAU DE CONTROLE	1	1	1	1	.	.	.	.	.
	10194-T501	CONTROL COVER	PANNEAU DE CONTROLE	.	.	.	.	1	1	1	1	1
32.	10338-T311	POST LEG	PIEDS	4	4	4	4	.	.	.	.	.
	S17317	POST LEG	PIEDS	.	.	.	.	4	4	4	4	4
35.	10184-T401	SUPPORT - CASTING - LEFT	SUPPORT GAUCHE DU FOYER	1	1	1	1	1	1	1	1	1
36.	10184-T411	SUPPORT - CASTING - RIGHT	SUPPORT DROIT DU FOYER	1	1	1	1	1	1	1	1	1
37.	S21345	PLUG - 1/2	EMBOUT DE JAMBE - 1/2	.	.	.	2	.	.	.	.	2
39.	10956-T401	BRACE - UPPER REAR	SUPPORT ARRIERE	1	1	1	1	.	.	.	.	.
	10956-T501	BRACE - UPPER REAR	SUPPORT ARRIERE	.	.	.	.	1	1	1	1	1
40.	S17346	SHELF - LOWER	TABLETTE INFERIEURE	1	1	1	1	.	.	.	.	.
	S17347	SHELF - LOWER	TABLETTE INFERIEURE	.	.	.	.	1	1	1	1	1
46.	S17106	BRACKET - CYLINDER LP	SUPPORT DU RESERVOIR PL	1	1	.	1	1	.	1	.	1
49.	10711-T461	CONDI-BIN	CONDI-BIN	.	1	1	1	.	.	.	.	1
	10711-T561	CONDI-BIN	CONDI-BIN	.	.	.	.	.	.	1	1	.
50.	10711-T451	SHELF - SIDE	PLANCHETTE LATERALE	2	2	2	.	.	.	.	.	.
	10711-K551	SHELF - SIDE	PLANCHETTE LATERALE	.	.	.	1	2	2	2	2	1
53.	S16138	SHELF BOARD - FRONT	PLANCHETTE AVANT	.	1	1	1	.	.	.	.	.
	S16139	SHELF BOARD - FRONT	PLANCHETTE AVANT	.	.	.	.	.	.	1	1	1
54.	10088-75	FRONT PANEL	PANNEAU AVANT	.	.	.	.	.	.	.	.	.