

PARTS LIST/LISTE DES PIECES

KEY NO.	ITEM #	DESCRIPTION	DESCRIPTION	202	212	302	312	322	352	412	414	422
49.	10711-T471	CONDI-BASKET	CONDI-BASKET	*	1	*	1	1	1	*	*	*
	10711-T671	CONDI-BASKET	CONDI-BASKET	*	*	*	*	*	*	1	1	1
50.	10711-T451	SHELF - SIDE	PLANCHETTE LATÉRALE	2	2	2	2	*	2	2	*	*
	10711-T651	SHELF - SIDE	PLANCHETTE LATÉRALE	*	*	*	*	1	*	*	2	1
54.	10088-55	FRONT PANEL	PANNEAU AVANT	*	*	*	*	*	*	*	1	*
55.	10184-K631	FRONT PANEL BRACKET	SUPPORT POUR PANNEAU AVANT	*	*	*	*	*	*	*	2	*
56.	S15075	WHEEL	ROUE	2	2	2	2	2	2	2	2	2
67.	10156-T40	HEAT SHIELD	ECRAN THERMIQUE	1	1	1	1	1	1	*	*	*
	10156-T55	HEAT SHIELD	ECRAN THERMIQUE	*	*	*	*	*	*	1	1	1
73.	S21420	NUT PUSH - 3/8	ECROU A PRESSER - 3/8	2	2	2	2	2	2	2	2	2
74.	S16178	AXLE	TOURILLON	1	1	1	1	1	1	1	1	1
75.	10339-143	HANDLE	POIGNÉE	1	1	2	2	2	2	2	2	2
76.	10239-5	WASHER - HANDLE	RONDELLE DE LA POIGNÉE	1	1	2	2	2	2	2	2	2
77.	S15111	GREASE CUP HOLDER	PORTE CONTENANT A GRAISSE	1	1	1	1	1	1	1	1	1
78.	S21346	PLUG	EMBOUT DE JAMBE	2	2	2	2	2	2	2	2	2
80.	Y-11549	BOLT - 1/4:20 X 1-7/8	BOULON - 1/4:20 X 1-7/8	1	1	2	2	2	2	2	2	2
81.	S21018	SCREW - 1/4:20 X 1-1/2	VIS - 1/4:20 X 1-1/2	12	12	12	12	12	12	12	12	12
82.	S21015	BOLT - 1/4:20 X 1	BOULON - 1/4:20 X 1	4	4	4	4	4	4	4	4	4
83.	S21141	BOLT - 1/4:20 X 5/8	BOULON - 1/4:20 X 5/8	1	1	1	1	1	1	1	1	1
85.	S21255	WASHER	RONDELLE	1	1	1	1	1	1	1	1	1
86.	Y-12658	PLUG - BUTTON	BOUCHON	*	*	*	*	*	*	*	2	*
87.	Y-11783	NUT - 1/4	ECROU - 1/4	17	17	18	18	18	18	18	18	18
88.	Y-11588	NUT WING - 1/4	ECROU PAPILLON - 1/4	1	1	1	1	1	1	1	1	1
91.	Y-11967	BOLT - 3/8:16 X 1-3/4	BOULON - 3/8:16 X 1-3/4	2	2	2	2	2	2	2	2	2
94.	Y-12285	NUT - 3/8	ECROU - 3/8	2	2	2	2	2	2	2	2	2
95.	Y-29305	BOLT 10:24 X 3/8	BOULON 10:24 X 3/8	2	2	2	2	4	2	2	2	4
98.	S21123	SCREW - 8 X 1/2	VIS - 8 X 1/2	12	12	12	12	13	12	12	12	13
99.	Y-12646	SCREW - SHOULDER	VIS	4	4	4	4	4	4	4	4	4
100.	S21084	SCREW - 14 X 3/4	VIS - 14 X 3/4	*	*	*	*	4	*	*	*	4
104	Y-12835	SCREW 6-32 X 1/4	VIS 6-32 X 1/4	*	*	*	*	5	*	*	*	5
105	Y-29307	NUT 10:24	ECROU 10:24	*	*	*	*	1	*	*	*	1
108	10472-71-2	KNOB	BOUTON	*	*	*	*	1	*	*	*	1
109	S21582	PUSH MOUNT CABLE TIE	LIEN EN PLASTIQUE	*	*	*	*	1	*	*	*	1
110	10225-T09	GRID	GRILLE	*	*	*	*	1	*	*	*	1
111	10380-T10	SIDE BURNER	BRULEUR DE COTE	*	*	*	*	1	*	*	*	1
113	10342-T08	ELECTRODE - SIDE BURNER	ELECTRODE - BRULEUR DE COTE	*	*	*	*	1	*	*	*	1
114	10383-T401	COVER - SIDE BURER	COUVERCLE DE BRULEUR DE COTE	*	*	*	*	1	*	*	*	1
116	Y-12848	SCREW 10:24 X 1/2	VIS 10:24 X 1/2	*	*	*	*	2	*	*	*	2
118	Y-12063	NUT 10:24	ECROU 10:24	*	*	*	*	2	*	*	*	2
117	10383-T32	SHELF - SIDE BURNER	SUPPORT DE BRULEUR DE COTE	*	*	*	*	1	*	*	*	1
118	10383-T221	SHIELD - SIDE BURNER	ECRAN DE CUVETTE DU BRULEUR DE COTE	*	*	*	*	1	*	*	*	1