

PARTS LIST / LISTE DES PIÉCES

KEY	ITEM #	DESCRIPTION	702-8	712-8	716-8	732-8	742-8	KEY	ITEM #	DESCRIPTION	702-8	712-8	716-8	732-8	742-8
1	S11425	CASTING BOTTOM	1	1	1	1	1	80	Y-11546	SCREW - 1/4-20 X 5/8	8	8	8	8	8
2	S11290	CASTING TOP	1	1	•	1	1	81	Y-11545	BOLT - 1/4-20 X 1-3/8	4	4	4	4	4
	S11296	CASTING TOP	•	•	1	•	•	82	Y-12855	BOLT - 1/4-20 X 3/8	14	14	14	14	14
3	S14018	NAMEPLATE	1	1	1	1	1	83	S21014	BOLT - 1/4-20 X 3/4	8	8	8	8	8
5	10571-6	HEAT INDICATOR	1	1	1	1	1	84	Y-12220	BUSHING	1	1	1	1	1
6	S21235	HINGE PIN	2	2	2	2	2	85	Y-11211	WASHER - LOCK 1/4	8	8	8	8	8
7	S21233	HINGE CLIP	2	2	2	2	2	86	Y-11795	NUT - 1/4	•	•	8	•	•
8	10222-T42	GRATE	1	1	•	1	1	87	Y-11793	NUT - 1/4	12	12	14	12	12
	10222-T424	FLAV-R-WAVE	•	•	1	•	•	88	Y-11598	NUT WING - 1/4	4	4	2	4	4
9	S12028	GRID	2	2	2	2	2	96	S21123	SCREW - 8 X 1/2	4	4	4	4	4
11	S12206	GRID RETRACTABLE	1	1	1	1	1	98	S21124	SCREW - 8 X 1/2	26	26	24	26	26
15	S10017	BURNER ASSY	1	1	1	1	1	99	Y-12646	SCREW - SHOULDER	4	4	4	4	6
17	10342-21	IGNITOR	1	1	•	1	•	101	Y-12853	WASHER - #8	•	4	4	4	4
	10342-241	ROTARY IGNITOR	•	•	1	•	1	104	Y-12835	SCREW - 6-32 X 1/4	6	6	8	6	6
	10472-K40	IGNITOR KNOB	•	•	1	•	•	105	Y-29307	NUT - 10-24	•	•	•	•	4
18	S15500	ELECTRODE	1	1	1	1	1	108	PB20-60	KNOB	•	•	•	•	1
21	10440-K51	CONTROL ASSY NG	1	1	1	•	•	109	S21136	SCREW 8-32 X 3/8	•	•	1	•	2
	10440-R52	CONTROL ASSY NG	•	•	•	1	•	110	10225-T10	GRID	•	•	•	•	1
	10442-R54	CONTROL ASSY NG	•	•	•	•	1	111	10390-E10	SIDE BURNER	•	•	•	•	1
21A.	S13467-132	HOSE-SIDE BURNER NG	•	•	•	•	1	113	10342-T12	ELECTRODE	•	•	•	•	1
	Y-11230	COTTER PIN	•	•	•	•	1	114	10393-K40	COVER - SIDE BURNER	•	•	•	•	1
21B.	10110-91	HOSE-REAR BURNER NG	•	•	•	1	1	115	Y-29304	SCREW 10-24 X 1/2	2	2	2	2	2
22	10111-K23	HOSE NG	1	1	1	1	1	117	10393-R50	SHELF - SIDE BURNER	•	•	•	•	1
23	10472-K36	CONTROL KNOB	2	2	•	3	4	OPTIONAL							
	10472-K37	CONTROL KNOB	•	•	2	•	•								
30	10086-R504	DECO PLATE	•	•	1	•	•								
	S14181	DECO PLATE	1	1	•	•	•								
	S14186	DECO PLATE	•	•	•	1	•	11300 PATIO BASE ASSY							
	S14187	DECO PLATE	•	•	•	•	1								
31	10194-K501	CONTROL COVER	1	1	•	1	1	40	10958-K811	PATIO BASE	1				
	10194-R561	CONTROL COVER	•	•	1	•	•	45	10184-K80	PATIO BASE - SUPPORT	1				
35	10184-K561	SUPPORT - CASTING-LH	1	1	•	1	1	48	10958-K561	POST BASE - BRACKET	1				
	10184-R561	SUPPORT - CASTING-LH	•	•	1	•	•	83	S21014	BOLT 1/4-20 X 3/4	4				
36	10184-K571	SUPPORT - CASTING-RH	1	1	•	1	1	85	Y-11211	WASHER - LOCK 1/4	4				
	10184-R571	SUPPORT - CASTING-RH	•	•	1	•	•	87	Y-11793	NUT 1/4-20	4				
37	10184-K581	SUPPORT - SHELF - LH	•	2	2	2	2	90	Y-12286	LAG BOLT - 5/16 X 4	4				
38	10184-K591	SUPPORT - SHELF - RH	•	2	2	2	2	92	Y-12851	WASHER - 3/8	4				
39	10958-K641	BRACE - REAR	1	1	•	1	1	11240 POST EXTENSION ASSY							
	10958-R831	BRACE - REAR	•	•	1	•	•								
41	10958-K631	BRACE - FRONT	1	1	•	1	1								
	10958-K851	BRACE - FRONT	•	•	1	•	•								
42	10958-K521	POST SUPPORT	1	1	1	1	1	43	10958-K55	POST - INGROUND	1				
46	10958-K531	POST	1	1	1	1	1	83	S21014	BOLT 1/4-20 X 3/4	2				
47	10958-K541	POST COVER	1	1	1	1	1	86	10958-K58	POST - BRACE	1				
49	10711-K541	CONDI - BIN	•	1	1	1	1	87	Y-11793	NUT - HEX 1/4-20	2				
50	10711-K551	SHELF - SIDE	•	2	2	2	1								
53	S16144-2	SHELF - BOARD - FRONT	•	1	1	1	1								
57	10156-K55	SHIELD	1	1	•	1	1								
65	S13009	BURNER ROTISSERIE	•	•	•	1	1								
68	S21362	SPRING	•	•	•	2	2								
70	Y-11990	HEX NUT	•	•	•	1	1								
71	10696-160	REAR BURNER-ORIFICE NG	•	•	•	1	1								
74	Y-6616	BOLT	2	2	2	2	2								
75	10338-145	RESIN HANDLE	2	2	2	2	2								
76	10239-7	WASHER - HANDLE	2	2	2	2	2								
77	S15111	GREASE CUP HOLDER	1	1	1	1	1								
79	Y-11561	SCREW 1/4-20	1	1	2	1	1								